









Instalation manual

SZAFKA RTV 140 INES 2




Element symbol	Dimensions	Code	Package
1	1379 450	RTV_2S_alyzi.001	1/2
2	1313 437	RTV_2S_alyzi.002	1/2
3	1313 437	RTV_2S_alyzi.003	1/2
4	652 220	RTV_2S_alyzi.004	2/2
5	652 220	RTV_2S_alyzi.005	2/2
6	227 415	RTV_2S_alyzi.006	1/2
7	1304 60	RTV_2S_alyzi.007	1/2
8	186 417	RTV_2S_alyzi.008	1/2
9	591 120	RTV_2S_alyzi.009	1/2
10	400 120	RTV_2S_alyzi.010	1/2
11	400 120	RTV_2S_alyzi.011	1/2
12	454 665	RTV_2S_alyzi.018	1/2
13	609 402	RTV_2S_alyzi.021	1/2
14	489 443	RTV_2S_alyzi.016	1/2
15	489 443	RTV_2S_alyzi.017	1/2


2x	p52 φ3x16 mm	2x	n260 φ3x16 mm
2x	L-400 400 mm	1x	y1
1x	z1	30x	f1 φ8x30 mm
40x	l1	30x	r1 φ1.5x12mm #16
24x	p25 φ3.5x16 mm	10x	s1
2x	p9 φ4x30 mm	2x	88532
5x	k1	30x	r16
30x	s2		




1




3




2




4




5




7



6



8



! a=b

